

Blackview

— Enjoy Smart Life —

NEST 15

<https://www.blackview.hk>

CONTENTS


English.....	1-5
Русский	6-10
Español	11-15
Deutsch	16-20
Français	21-25
Italiano	26-30
Português	31-35
日本語	36-40




Scan the QR Code to
download the detailed
user manual.

Bracket Installation Guide


Accessories



Lay on the table - Horizontal



Lay on the table - Vertical



Wall-Hanging Method

Accessories



x 2





x 2





x 1

1. Wall-hanging--Horizontal



2. Wall-hanging--Vertical

Put 1 set screw into the wall and locate any position you want to hang.




Bracket Method (Note: Accessories need to be purchased separately.)


Accessories





Bracket Installation Instructions



Fasten the bracket base to the wall with long screws.



Secure the bracket onto the calendar machine using short screws.



Mount the calendar machine onto the bracket.

Note: Brackets and screws shall be purchased by yourself. The figure here is merely for installation demonstration.

Operating Instructions


STEP 1: Plug in the Frame.

Unbox the frame and connect it to an AC outlet. The calendar frame will power on automatically.

STEP 2: Select Language, connect to Wifi, and Select Time Zone.

1. Select your preferred language after the device powers on.
2. Go to Wi-Fi settings and connect to a network.
3. Use the touchscreen to select your Wi-Fi from the list, and enter the password if required.
4. Select your time zone.

STEP 3: Download the DK Calender App and Scan to Log In



Operating Instructions


STEP 4: DK Calender Login & Frame Binding

DK Calender App Login Methods

Sign up or log in using your email address, or log in with your Google or Apple account.

After successful login

Open the app and tap the scan icon in the top right corner. Scan the QR code displayed on the digital photo frame to log in and sync your cloud data.






Facebook Group




Facebook



YouTube



TikTok




Instagram

Manufacturer: Shenzhen Doke Communication Co., Ltd
Address: No. 1301-1302, Block B, Weidonglong Business Building, No. 2113 Meilong
Avenue, Qinghua Community, Longhua Street, Longhua District, Shenzhen, China



www.blackview.hk



The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 24 Watts in order to achieve the maximum charging speed.